

42 43 44

24 25

1 2


3

21 22 23


10 11 12 13 14

56 57 58 59 60 61 62 63

5 6 7 8 9



23



5. Laskusiivekkeiden käyttö